



- C1 = 3 Gang Condenser
- C2 = Padder
- C3 = .1 m.f.
- C4 = .01 m.f.
- C5 = .02 m.f.

- C6 = 5 m.f. Condenser
- C7 = 25 m.f.
- C8 = .0001 m.f.
- C9 = .0008 m.f.
- C10 = .006 m.f.

- C11 = 8 m.f. Condenser
- C12 = 8 m.f.
- C13 = .05 m.f.
- R1 = 200,000 ohm resistor
- R2 = 50,000 "

- R3 = 500,000 ohm resistor
- R4 = 1 megohm resistor
- R5 = 20 " C.T.
- R6 = 250 ohm resistor
- R7 = 3000 ohm "

- R8 = 5000 ohm resistor
- R9 = 110 "
- R10 = 400 "
- S P 22 A 4 1/2 E T C T R P 2 P C T
- S P 22 A 4 1/2 E T C T R P 2 P C T
- S P 1 2 5 2 P F C 500 ohm